Coat rack Jack

Installation Manual

Contents

|		
4st	lag screw	
4st	Plug	
4st	Sealing cap	

Supplies

- Pencil
- Level
- Impact drill
- Stone drill Ø8mm
- Socket wrench 10

01| Preparation wall

It is recommended to install the coat rack with two
or more people.

160 - 170 cm

Determine the desired height for the coat rack. The average height for a coat rack is between
160 and 170 cm from the ground.

Hold the coat rack against the wall at the desired height and mark the holes at the four
positions marked in red.
Make sure that the coat rack hangs level

Drill the holes at the marked positions.

Add the plugs to the pre-drilled holes.

Fix the coat rack to the wall with the four lag screws. Use a socket wrench for this.

Seal the holes in the coat rack with the four sealing caps supplied

Thank you for your purchase!

Have fun with your coat rack | Jack

Indusigns

van ontwerp tot realisatie